

MC450 ADAPTER KIT

#37-9888 (FOR USE WITH MC450 WITH RUBBER PAD INSTALLED. FIG 3)

#37-9894 (FOR USE WITH MC450 WITHOUT RUBBER PAD. FIG 2)

Thank you for purchasing this K&L Product.

Please inspect this unit for damage/missing parts prior to use.

1. Slide the two adapter mounts onto the MC450 Center Jack. This kit comes with two height adjustment posts, 1.5" and 3.0".
2. After selecting posts, slide them into adapter mounts. See Fig 1
3. Raise the Center Jack posts until they contact frame rails. Posts should not contact hoses, cables, etc. See Fig 2
4. After all areas have been checked, raise bike to desired height.



Fig 1



Fig 2



Fig 3